

***** UPHOLSTERY KIT PACKING LIST – All 750 Models *****

CUSTOMER: _____ MODEL: _____ SERIAL #: _____

Ordering Instructions: First, select the desired material (Vinyl or cloth); then respond at each arrow (A, B, and C).

- ➡ **A) Material Desired (circle one):** Two-Tone Gray VINYL or Two-Tone Gray CLOTH
- ➡ **B) Stick Style (circle one):** Standard Center “Y” or Optional Dual Stick
- ➡ **C) Center Console (circle one):** “NO” (Standard) or “Yes” (Optional)



Note: Material for Cabin Sides is included but not assembled to allow for custom trimming & adjustments (see instructions)*

CH 750 Upholstery Kit Packing List (STOL, CRUZER, SUPER-DUTY)

PART NO:	DESCRIPTION	QTY	SHIPPED	BACK-ORDERED
750-USBT	Seat Bottom	2		
750-USBK	Seat Back	2		
750-UDC	Dashboard Cover – Black color	21" x 61"		
750-UDES	Dashboard Edge Seal	48"		
750-USS	Snap Studs	8		
A4	Rivets for Snap Studs	8		
750-CSP	Cabin-Side Panels (1L+ 1R) – Cut & trim to fit airframe*	2		
750-CSF	Cabin-Side Foam (1L+ 1R) – Cut & trim to fit 750-CSP*	2		
750-CSM	Cabin-Side Material (Vinyl or Cloth) (1L+ 1R)*	2		
750-SB1 or SB2	Stick Boot and Cover (as per “B” above)	1		
750-UEM	Extra Material – for use on Center Console if installed	18" x 56"		
750SD-BSC	Back Seat Cushion (for Super-Duty model only)	1		
750SD-BSB	Back Seat Backrest (for Super-Duty model only)	1		
Optional:				

***Cabin sides:** Using cardboard, cut a template that covers the desired area of the cabin-side, between the front of the seat and the firewall. Take into account any cables, wires and/or fuel lines that need to be covered or accommodated by your side panels (note: The left side may differ slightly from the right side). Plan your securing method (type and location of fasteners) as you shape & position your panels; you can use the existing fuselage structure where appropriate.

Use your template to trace and cut-out your L & R side-panels from the provided aluminum panels (P/N 750-CSP). Cover your panel with a layer of foam (P/N 750-CSF); then cover the foam with the vinyl or cloth material (P/N 750-CSM), also provided in the kit. Note: Cut the cloth approx. 1” larger than the foam-covered panel all around, so that you can wrap it over the edge, pull it tight and glue it in place with contact cement.

Insert your finished cabin-side panels into the aircraft and secure them in place. Confirm that they cannot come loose and/or interfere with the operation of the aircraft systems (controls, fuel, electrical, etc.). Customize as desired...

